

How to Design and Install Bevel Gears for Optimum Performance: Lessons Learned

Stephen Marsh

Introduction

Bevel gears must be assembled in a specific way to ensure smooth running and optimum load distribution between gears. While it is certainly true that the “setting” or “laying out” of a pair of bevel gears is more complicated than laying out a pair of spur gears, it is also true that following the correct procedure can make the task much easier. You cannot install bevel gears in the same manner as spur and helical gears and expect them to behave and perform as well; to optimize the performance of any two bevel gears, the gears must be positioned together so that they run smoothly without binding and/or excessive backlash.

Bevel gears can include straight, spiral, Zerol, hypoid and Spiroid (to address the differences between each one is beyond the scope of this guide). Because these types of bevel gears are basically conical in shape, they all have an optimum position for best performance. Usually the manufacturer of the bevel gear determines this optimum position by running tests of individual gear sets. However, the *gearbox designer* and *assembly technician* share responsibility for incorporating this optimum positioning in the gearbox. The designer must provide shimming dimensions that are easy to measure in order to aid the fitter/technician in assembling the overall gearbox. The aim of this guide is to provide instruction on how best to accomplish this.

Part I: Key Factors

Various parameters contribute to proper gearbox assembly that help ensure smooth and efficient operation; the two most important criteria are:

1. Mounting distance
2. Backlash

Mounting distance. The distance from a locating surface on the back of one gear (most commonly a bearing seat) to the center-line of a mating gear is the mounting distance (Fig. 1). In some cases, for convenience, a front surface may be used for




Figure 1 Gear showing make-up of the mounting distance.

the assembly. This is the most important parameter for ensuring correct and optimal operation.

Typically, the pitch cone apex-to-crown-value is a fixed, nominal value determined by a formula. The dimension between the mounting surface (in Figure 2 it is the bearing seat) and the crown point will have a tolerance; it is common to see a tolerance of ± 0.05 mm up to ± 0.1 mm. Obviously the mounting distance is the addition of the two values and will therefore also have a tolerance.

For straight bevel gears, the pitch cone apex is the intersection point of the pinion and gear axes (Fig. 2).

The pitch cone apex-to-crown-value is provided in engineering handbooks and in publications provided by Gleason Corp., for example. Gleason publications include most of the information required by the gear designer to select a satisfactory pair of bevel gears. The pitch cone apex-to-crown value is determined by a formula that is a function of the pitch diameter, pitch angle and addendum; therefore, the pitch cone apex-to-crown-value cannot be chosen arbitrarily. However, the mounting distance is determined by the designer as long as the pitch cone apex-to-crown-value is maintained. (Of course, in reality this mounting distance will have to have some degree of tolerance.) It may be possible to manufacture all gears to the nominal mounting distance specified on the drawing, but the additional cost to do so is usually not warranted.

If two gears are being machined as a set, the manufacturer can establish the optimum value for this distance by running the gear set and adjusting its position to obtain a tooth contact pattern that is consistent with smooth running and optimum load distribution between mating gear teeth. The optimum mounting distance can then be recorded.

Because of dimensional variations between parts, each gear will have a unique value for the mounting distance and, in most cases, the manufacturer permanently marks this value onto each gear; the mounting distance will be within the tolerance




Figure 2 Assembly of a pair of straight bevel gears (pinion and gear).

specified on the drawing. Manufacturers aim for a tolerance of ± 0.05 mm from the nominal value. If, at assembly, the mounting distance of one or both gears is made at less than the dimension specified, the teeth may bind, and excessive wear or breakage can result. If the mounting distance of either gear is made longer than the dimension specified, the gears will not be in full mesh on a common pitch line and may have excessive backlash.

Backlash. The second most important variable for a pair of bevel gears is backlash—i.e., the space between mating gear teeth or the difference in width of the gear tooth and pinion tooth of the mating gear. Unless otherwise specified, it is measured at the tightest point of the mesh.

Backlash is necessary to achieve correct operation of the gears and varies with the size of the tooth and operating conditions. Bevel gears are cut to have a definite amount of backlash when correctly assembled together. But excessive backlash or play, if great enough, can cause a sudden impulse or shock load in starting or reversing that may cause serious tooth damage. Excessive or insufficient backlash can also result in noise, excessive wear and damage. Backlash can be changed by changing the position of one or both gears.

General Notes for the Design Engineer

Gearbox housing/mounting. It is very important that the designer consider the mountings for the gear and pinion so that they are rigidly supported to handle all loads to which the gears will be subjected in service. It is equally important that the designer detail the housing or mounting parts (e.g., bearing cap) with adequate tolerance for alignment, squareness, fits, and run-out, etc. While bevel and hypoid gears can accommodate reasonable displacements and misalignments without detriment to tooth action, excessive misalignment of the gears reduces their load capability, with the consequent danger of surface failure and breakage while in service.

Provision should be made by the designer in the design of the housing and mounting parts so that both the pinion and gear mounting distances can be adjusted. This is usually done using shims. Determining the range of shim thicknesses can be calculated by the designer so that the mounting distances of the gears are always maintained. An example of setting up gears and determining the range of shims is explained in more depth later in this guide.




Figure 3 Ideal contact pattern under load (Ref. 2).

It is good practice for the designer to make provision so that the teeth can be inspected and that assembly personnel can also check for backlash, etc. This feature can also be used for inspection during service to check the condition of the teeth without disassembling the gearbox. Once the components are machined, they must be fully inspected to check the housing and mounting components for errors. While the shaft angles, offset and mounting distances are the usual items to check, the alignment of the bores and the squareness of the bearing seats are also important.

Bearings. While bearings are not a focus of this guide, it must be noted that the bearings of a gear system are responsible for holding the components in position, absorbing and distributing forces and moments, and assuring the rotation of shafts and gears. Any clearance in the radial and axial directions inside the bearing can be adjusted by axial pre-loading of the inner or outer ring or race. This pre-loads the rolling bodies and bushings and achieves a stiff, play-free radial and axial support bearing.

Ideally, the bearing manufacturer should be consulted regarding the selection of bearings suitable for the radial and thrust loading required to maintain the alignment and position of the bearing and pinion. The axial and radial movement of the bearings should not allow the load to substantially shift, and the bearings should be stiff enough to prevent deflection in order to maintain proper contact. Deflection of the bearing shaft and the housing are all influenced by bearing contact. It is highly recommended that the bearings be pre-loaded; this should be mandatory—even in cases of small bevel gear sets with low torque transmission.

Solid pre-load is obtained by mechanically locking the races of the bearing into position with the aid of shims. The shims and, hence, bearing races, spacers, etc., are subjected to an axial load; this axial load is commonly provided by the end-caps. By adjusting the thickness of the shims, the amount of pre-load can be increased or decreased. This must be taken into account when determining the range of shims during the design stage and determining the actual size of the required shim at assembly. The disadvantage of the solid pre-load method, however, is the high variation in pre-load as temperature changes, and its reduction as the bearing wears. Pre-loads can be applied by a spring to counteract this and provide a consistent pre-load as temperature varies, but generally this solution is more complex and is beyond the scope of this guide.

It must be remembered that excessive pre-load will reduce the life of the bearing and increase the amount of noise produced and heat generated, as well as the bearing starting and running torque. The amount of pre-load required is determined by virtue of design and stress analysis.

Contact pattern. A critical attribute of any bevel gear design is its contact pattern (Fig. 3).

Simply stated, the contact pattern is the area in which the gear teeth come in contact as they engage and disengage during their rotation. When a gear is installed in a gearbox and is powering the designated application, there are varying degrees of pressure—or load—on the gear teeth. These pressures are influenced by box deflections, bearing movement and temperature changes. When the gear teeth are subjected to these variables, the contact

pattern will change. There is a general rule of thumb stating that the heavier the load, the larger the contact pattern.

For a gear to perform properly under load, the contact pattern must be a certain shape and at a certain location. Typically, an ideal tooth contact pattern under load should encompass the bulk of the tooth surface while avoiding any contact with the edges of the tooth surface.

When assessing how the contact pattern will perform in an operating gearbox, another critical issue to consider is gear displacement. In the operation of many gearboxes, the gears and their shafts do not remain in a fixed orientation. Thermal forces and stress from being under load can cause significant movement of the gearbox components from their original positions.

There are typically four different types of movement that can take place (Fig. 4).




Figure 4 Gear displacement conditions (Ref. 2).

It is this movement that is referred to as “gear displacement,” and it can occur in any combination of the four types. In aerospace gearboxes, where keeping weight to a minimum is a high priority, the mass of the gearing used is usually smaller and these displacements can be significant. On the other hand, in commercial applications—where the gearbox components are typically more rigid—there is not the same degree of displacement.

A question could be asked by the designer: “What is the best way to maintain the correct mounting distance and corresponding tooth contact pattern?” And that very question is the “fly in the ointment” in determining the setting position.

Bearings play a significant part in setting proper position. The real issue is not so much where and how one sets it; but more in how the gears run. If the bearings are assembled with pre-load, then there is usually not much variation in measurement. However, it must be remembered that one is essentially working with some elasticity in the components and the dimensional changes are small. There is always some variation in measurement and shim sizes in the nature of one- or two-thousands of an inch, but bevels are not normally that sensitive where it could be considered a problem.

End-play, however, can cause quite a problem. The traditional response would be to set the gears in the position they would run. That is, if the gears will move in a particular direction under load, force them that way at assembly, taking out end-play in that direction. But if the gears run in both directions, or the operating conditions greatly affect the end-play or position, the technique is not so simple. Bearings typically like to run at a pre-load; if operating conditions are stable and the housing and shafts do not move or grow, the pre-load can be built in at

assembly. Ideally, that is the case. However, if there is growth or movement (especially with an aluminum gearbox housing), it would be ideal for the bearings to go to light pre-load so all the rotating elements share the load.

If an advanced analysis of the system design in order to predict its growth and movement have been done, the results could be used to compensate for position at assembly. (Note here that these results should be considered in the bevel design to manufacture the teeth with the proper loaded tooth contact pattern.) Most gear designers/manufacturers cannot predict how the components will be affected in service and, unfortunately, there is only one solution—research and development.

In an ideal world, the first build could be assembled using all the advanced analysis and techniques discussed in this guide. Then the gearbox could be run at operating conditions and checked to see what happened at the contact areas. The gearbox could be stripped and re-shimmed to compensate. What everybody is *really* looking for is, “What is the *loaded* contact pattern?”

Regardless of how it looked at assembly, it is how it runs that matters most.

Part II: Determining Thickness Range of Shims at Design Stage

When laying out a pair of bevel gears, the designer should always begin with the pitch cone apex-to-crown dimensions. These will have been determined by formula, and their values depend on the size of the gears. Once the pitch cone apex-to-crown-value has been established, the designer can determine suitable locating surfaces on the back of the gears. It is recommended that this mounting surface be the seat/shoulder for a bearing; otherwise, it is okay as long as the designer makes the mounting surface a flat surface perpendicular with the axis of the gear/pinion.

The designer must lay out the gears, bearings and spacers, etc. inside the housing so that shims may be used to position the pinion/gear in its correct mounting distance. The designer must arrange the components and assign the appropriate tolerances so that the shim thickness does not fall below 1 mm or exceed 5 mm. If this tolerance analysis has not been properly done, the designer could end up with a negative-value shim (which, of course, cannot physically happen). On assembly, the fitter would have to modify the actual components in order to situate the gear into the correct mounting distance. When the fitter/technician is assembling the gears and is adjusting their position along their axes to achieve smooth running, it may be necessary to adjust the shims. It is far better to adjust shims than to make changes to the housings, end-caps or the gears. This is why the range of shims should be between 1 mm and 5 mm. A shim below 1 mm would be extremely hard to manufacture and handle; it's basically dealing with a sliver of metal. A shim over 5 mm indicates the designer should probably tighten some tolerances or change the nominal size of some components in attempting to reduce this range.

If a worst-case scenario ever arose, it would be more desirable to re-machine the housing rather than re-work the gears to accommodate errors in the mountings. Re-working the gears to accommodate angle or offset errors in the housing is a criti-

cal process and should be undertaken only as a last resort; the results are usually not satisfactory.

It is important that the designer think about shimming and setting up the correct mounting distance, as bevel gears are conical in shape and so can be assembled in an almost infinite number of positions (most of which will cause poor performance) and still obtain the required backlash. An inexperienced fitter could in theory assemble bevel gears to obtain a specific amount of backlash without regard to the mounting distance; this is especially true for low-quality or lightly loaded bevel gears. Although this method occasionally works, it is a risky approach where gears are loaded to maximum capacity. It usually causes shorter life and poor performance. Only at the proper mounting distance will a gear set run smoothly and still have the right amount of backlash.

This guide has been written to show the designer a method of determining the size range of shims in a typical gearbox. An example has been included with an in-depth methodology so that a designer can apply the method to other similar gearboxes.

This example gearbox incorporates bevel gears at right angles and bevel gears at an acute angle; this method can also be used for bevel gears at an obtuse angle (Fig. 5).

To begin, the designer can choose any bevel gear in determining the range of shims for that specific gear. For assembling by the fitter, the center gear would be the logical starting point (Fig. 6).

First, the designer positions the pitch-cone apex of the gear on the intersection point of the two bores in the housing. It can be seen that the bores are at an acute angle with one another.

The size range of the first shim can be determined so that the pitch-cone apex of the gear always remains approximately on the intersection point of the two bores. However, it has already been established that the exact mounting distance is not marked onto the gears and, in reality, it would be nearly impossible to measure the intersection of the two bores (as the point exists in space and the bores are at an acute angle) without use of highly specialized and expensive measuring equipment. In practice, the fitter sets the pitch-cone apex of one gear as close as possible to the theoretical intersection of the bores (using the nominal value of the mounting distance and the nominal value of the intersection point) with the use of shims. The fitter then positions the mating gear so that it comes into contact with its counterpart, after which the fitter would physically turn the gears to check for smooth running, adjusting the shims as needed. Once the fitter is satisfied that the gears are running smoothly, he will then measure the backlash to determine if its value is within the backlash limits specified on the drawings.

To make sure that the fitter uses a shim in a range of 1 to 5 mm, the designer has to allow for this fitting process and imagine that the bevel gear is being positioned so that the apex point sits on top of the intersection point. As is known, this will never be exact, so the designer has to assign a ± 0.15 (a conservative figure) to the nominal value of the theoretical intersection point. This is the setting distance for the gear, so that the apex point is theoretically "floating" in this range. This should allow for any tolerance build-up of the mating gear's mounting distance, the tolerance of the actual mating gear's teeth, the tolerance of the true intersection point, etc. Figure 7 diagrams a




Figure 5 Example gearbox incorporating bevel gears at right angles and bevel gears at an acute angle; this method can also be used for bevel gears at an obtuse angle.




Figure 6 Designers can choose any bevel gear in determining the range of shims for that specific gear. For assembling by the fitter, the center gear would be the logical starting point.

method for determining the maximum and minimum thickness of the first shim.

The 0.025 value is shown (Fig. 7) to account for the shift of the inner and outer races due to the axial pre-load.

Determining Maximum First Shim

Maximum Mounting Distance + Maximum Race of Bearing + Axial Play = A

$$62.45 + 13 + 0.025 = 75.475$$

Minimum Setting Distance of Gear: A = B

$$115.85: 75.475 = 40.375$$

Maximum Depth of Bore: (B + Minimum Race of Bearing) = Maximum Shim

$$55.95: (40.75 + 12.88) = 2.695$$




Figure 7 Diagram of a method for determining the maximum and minimum thickness of the first shim.

Determining the Minimum First Shim

Minimum Mounting Distance + Minimum Race of Bearing = A
 $62/35 + 12.88 = 75.23$
 Maximum Setting Distance of Gear: A = B
 $116.15: 75.23 = 40.92$
 Minimum Depth of Bore: (B + Maximum Race of Bearing + Axial Play) = Minimum Shim
 $55.75: (40.92 + 13 + 0.025) = 1.805$

Knowing the range of the first shim, the designer can calculate the size range for the second one.

Determining the Maximum Second Shim

Maximum Depth of Bore: (Minimum First Shim + Minimum Thickness of all Components) = Maximum Shim
 $55.95: (1.805 + 12.88 + 12.2 + 12.88 + 13) = 3.185$

Determining the Minimum Second Shim

Minimum Depth of Bore: (Maximum First Shim + Maximum Thickness of all Components) = Minimum Shim
 $55.75: (2.695 + 13 + 0.025 + 12.3 + 13 + 0.025 + 13.2) = 1.505$

If the minimum thickness of the shims fell below 1 mm, the designer would have to tighten the tolerances or change the nominal size of a component.

The designer can now calculate the size range of shims for the center gear (Fig. 8).

Figure 9 shows the detail for the second bevel gear on the shaft.

Determining the Maximum First Shim

Maximum Mounting Distance + Maximum Race of Bearing + Axial Play = A
 $38.547 + 15 + 0.025 = 53.572$
 Minimum Setting Distance of Gear: A = B
 $99.57 - 53.572 = 45.998$
 Maximum Depth of Bore: (B + Minimum Race of Bearing) = Maximum Shim
 $63 - (45.998 + 14.88) = 2.122$

Determining the Minimum First Shim

Minimum Mounting Distance + Minimum Race of Bearing = A
 $38.447 + 14.88 = 53.327$
 Maximum Setting Distance of Gear: A = B
 $99.87 - 53.327 = 46.543$
 Minimum Depth of Bore: (B + Maximum Race of Bearing + Axial Play) = Minimum Shim
 $62.8 - (46.543 + 15 + 0.025) = 1.232$

Knowing the range of the first shim, the designer can calculate the size range for the second one. The second shim is important here as it will set up the mounting distance for the second bevel gear that shares the same shaft as the first.

Determining the Maximum Second Shim

Maximum Bore Depth + Maximum Setting Distance Second Gear = A
 $63 + 5.435 = 68.435$
 Minimum First Shim + Minimum Race of Bearing + Minimum Mounting Distance Second Gear = B
 $1.232 + 14.88 + 49.285 = 65.397$
 A - B = Maximum Shim
 $68.435 - 65.397 = 3.038$

Determining the Minimum Second Shim

Minimum Bore Depth + Minimum Setting Distance Second Gear = A
 $62.8 + 5.135 = 67.935$
 Maximum First Shim + Maximum Race of Bearing + Axial Play + Maximum Mounting Distance Second Gear = B
 $2.122 + 15 + 0.025 + 49.385 = 66.532$
 A - B = Minimum Shim




Figure 8 Designers can now calculate the size range of shims for the center gear.

$$67.935 - 66.532 = 1.403$$

Determining the Maximum Third Shim

Maximum First Shim + Minimum Second Shim + Maximum Thickness of all Components + Axial Play = A

$$2.122 + 15 + 0.025 + 1.403 + 15.6 + 12.7 + 0.025 + 13.95 = 60.825$$

Maximum Depth of Bore: A = Maximum Shim

$$63 - 60.825 = 2.175$$

Determining the Minimum Third Shim

Minimum First Shim + Maximum Second Shim + Minimum Thickness of all Components = A

$$1.232 + 14.88 + 3.038 + 15.4 + 12.573 + 13.75 = 60.873$$

Minimum Depth of Bore: A = Minimum Shim

$$62.8 - 60.873 = 1.927$$

The designer can now calculate the size range of shims for the third and final gear (Fig. 10).

Determining the Maximum First Shim

Minimum Setting Distance of Gear: Maximum Mounting Distance = A

$$35.35 - 27.675 = 7.675$$

A + Minimum Thickness of Components = B

$$7.675 + 10.95 + 38.875 + 8.88 = 66.38$$

Maximum Depth of Bore: B = Maximum Shim

$$69.1 - 66.38 = 2.72$$

Determining the Minimum First Shim

Maximum Setting Distance of Gear: Minimum Mounting Distance = A

$$35.65 - 27.575 = 8.075$$

A + Minimum Thickness of Components = B

$$8.075 + 11.05 + 38.925 + 9 + 0.025 = 67.075$$

Minimum Depth of Bore: B = Minimum Shim

$$68.9 - 67.075 = 1.825$$

Determining the Maximum Second Shim

Maximum Bore Depth + Maximum End-Cap Mounting Face to Shim Seat = A

$$69.1 + 4.1 = 73.2$$

Minimum First Shim + Minimum Thickness of all Components = B

$$1.825 + 8.88 + 38.875 + 10.95 + 9.88 = 70.41$$

A - B = Maximum Shim

$$73.2 - 70.41 = 2.79$$




Figure 9 Detail for the second bevel gear on the shaft.




Figure 10 Designers can now calculate the size range of shims for the third and final gear.

Determining the Minimum Second Shim

Minimum Bore Depth + Minimum End-Cap Mounting Face to Shim Seat = A
 $68.9 + 3.9 = 72.8$
 Maximum First Shim + Maximum Thickness of all Components = B
 $2.72 + 9.00 + 0.025 + 38.925 + 11.05 + 10 + 0.025 = 71.745$
 A-B = Minimum Shim
 $72.8 - 71.745 = 1.055$

It must be pointed out again that at this stage the designer is not calculating the actual thickness of the shims, but is determining their maximum and minimum thickness limits. The range will most likely be conservative, so as to avoid any future problems at the assembly stage. The designer is allowing for: tolerance build-up of all the individual parts; the true value of the mounting distance; how the fitter positions the pinion/gear inside the housing (which determines where the pitch-cone apex of the gear will be in relation to the intersection point of the bores in the housing); tooth thickness; how the teeth contact and interact with one another; and how the fitter determines "smooth running." It is better to have a large range of shim sizes on hand than to find out later that the fitter needed a 0.2 mm shim to set the gear at its proper mounting distance at the assembly stage. Proper design will allow the gears to interact smoothly so that the contact pattern on each tooth shares the load evenly and that the contact pattern does not shift towards the edge of the teeth.

Assembling Bevel Gears and Determining Actual Shim Size

Once the designer is satisfied with the design of the gearbox and has made allowances for the range in shim sizes, the fitter is charged with ensuring proper assembly. The only adjustments the fitter can control are those that axially position pinion and gear at assembly. In certain circumstances the fitter may not be provided with a means of shimming or other methods for positively locating the axial positions of the gears. The assemblies resulting from such inadequate designs will be affected by maximum tolerance accumulations and, in many cases, will not exhibit a good tooth contact pattern.

In gear sets where the mounting distances are known (either marked on the gear or the nominal size on the drawing) and provisions are made for shimming, the fitter should shim to achieve these mounting distances. These adjustments eliminate the effects of axial tolerance accumulations in both the gears and mountings. Shimming however, cannot correct shaft angle or offset errors.

In most bevel gear sets, particularly those with ratios above 2:1, the pinion position (mounting distance) affects tooth contact (the most important parameter for good performance) to a larger extent than does gear position. Conversely, the gear position has a larger effect on backlash.

For this reason the manufacturer may have marked the mounting distance only on the pinion. In such cases, be sure to first accurately position the pinion according to




Figure 11 Section of a gearbox; the fitter should start with the center gear as the datum pinion.




Figure 12 Location of shims.




Figure 13 Bevel gear assembly.

its marked mounting distance (or nominal value from drawing), and then adjust the gear position for the required backlash.

Where mounting distances have been marked on both pinion and gear, adjust these distances first and then use the normal backlash value to verify proper assembly. Again, the backlash value should be measured *after* assembling the pinion at its marked mounting distance.

It is recommended that the pinion be positioned first to its correct mounting distance when installing a pair of bevel gears. The principal methods for positioning the pinion are:

- **Gaging.** A set-up gage assembled in the housing in place of the pinion.
- **Direct measurement.** Measurements from the locating surface on the pinion to the axis of the mating gear.
- **Flush surfaces.** In the case of large bevel gears where direct measurement of mounting distance is difficult, a flat is hand-ground on the back cone faces (back angles) of the gear and pinion when in correct position on the testing machine. When the gears are assembled, they are positioned so that the ground flats on the back cone surfaces are flush.

The first method of using gages is used mostly for large gear production runs and is based on the direct measurement method. For this reason, only the measurement method is described in detail in this guide. These measurements may be made by means of inside and outside micrometers, depth micrometer, gauge blocks or a special gauge manufactured for this purpose.

The third method for positioning the pinion exists but is not recommended because the pinion and gear need to be manufactured as a gear set (matched pair). If the surfaces have not been ground as in the third method, then note that when mating gears are adjusted to their optimum position, their back angles will probably not be flush with each other. *Do not attempt to position bevel gears by making the back angles flush.*

To position the pinion by the measurement method, all the components that affect the location of the pinion must be directly measured.

In an ideal world, to aid the fitter at assembly all the housing measurements would be marked on the gearbox housing after it has been machined and inspected. For example, the distance from the locating surface to the adjacent bore center-line could be marked.

Measurements involving the pinion and gear should be taken on the sub-assemblies, which consist of the gear, shaft, spacers, bearings and gear-mounting components. This will minimize any variations due to fits between these components and greatly reduces the number of measurements required.

This example gearbox incorporates bevel gears at right angles and bevel gears at an acute angle (method can also be used for bevel gears at an obtuse angle). It is the same example that was used to determine the range of shims earlier in this guide. Figure 11 shows a section of a gearbox; the fitter should start with the center gear as the datum pinion.




Figure 14 Intersecting bores inside housing.

The fitter would measure to the following method:

- Dimension 1 = Measure gearbox housing end-face to adjacent bore center-line.

If the mounting distance is not marked on the part, the middle value (nominal figure) of the maximum and minimum size of the mounting distance is to be used.

- Dimension 2 = Bevel gear assembly mounting distance = 38.497

- Dimension 3 = Measure Depth of Housing Bore

$$\text{SHIM 1} = \text{DIM 2} - (\text{DIM 1} - \text{DIM 3})$$

In this example the intersection of the adjacent bore is at an acute angle and the intersection point exists in space; this makes it extremely difficult for the fitter to measure this dimension without highly specialized measuring equipment. The designer therefore has to assign a nominal dimension on the sectional drawing to aid the fitter in assembly.

When the shaft angle is other than 90°, the distance from the pinion mounting face of the housing to the crossing point is not easily measured, as stated above. This dimension can, however, be easily obtained during the machining of the housing, and either the actual dimension or the deviation from the mean can be marked onto the housing. With this dimension available, the necessary shim can be determined in a manner similar to a pinion having a 90° shaft angle.

- Dimension 4 = Intersection point of bores from end-face = 5.285

- Dimension 5 = Measure over inner race of bearing

- Dimension 6 = Second bevel gear mounting distance = 49.335

$$\text{SHIM 2} = (\text{DIM 3} + \text{DIM 4}) - (\text{SHIM 1 THICKNESS} + \text{DIM 5} + \text{DIM 6})$$

- Dimension 7 = Measure over two bearings, shim 2 and second bevel gear width

- Dimension 8 = Measure end-cover depth (mounting surface to bearing seat)

$$\text{SHIM 3} = \text{DIM 3} - (\text{SHIM 1 THICKNESS} + \text{DIM 7} + \text{DIM 8})$$

The fitter must now adjust the shim to ensure pre-load on the bearings. This can be achieved by ensuring a 0.05 mm (for example) space exists between the end-cover and housing mounting face. The fitter would achieve this by adding 0.05 mm




Figure 15 How pre-load is applied to the bevel gear.




Figure 16 Location of shims.




Figure 17 Bevel gear assembly.

to the already calculated shim size, so when the bolts are tightened it axially loads all the bearings.

The fitter would measure to the following method for the second gear:

- i) Dimension 9 = Measure gearbox housing (shim seat) to adjacent bore center-line
- ii) Dimension 10 = Bevel gear assembly mounting distance = 27.625
- iii) Dimension 11 = Measure assembly over bevel gear width, carrier shaft and bearing
- iv) Dimension 12 = Measure over inner race of bearing and record for later

$$\text{SHIM 4} = (\text{DIM 9} + \text{DIM 10}) - \text{DIM 11}$$

Assemble gear to pinion. If assembling a gear set, make sure that the matched teeth are properly engaged. The fitter now has

to rotate the gears and check for smooth running. If necessary, adjust the shim to ensure smooth running. Only after positioning both gears at their mounting distances, and the fitter is satisfied with the "smooth" running, should the fitter measure the normal backlash to verify proper assembly. The fitter should measure at the tightest point of the mesh between the gears.

- vi) Dimension 13 - Measure Housing Bore Depth from Flange Face
- vii) Dimension 14 - Measure End Cap mounting face to Bearing Seat

$$\text{SHIM 5} = (\text{DIM 13} + \text{DIM 14}) - (\text{SHIM 4} + \text{DIM 11} + \text{DIM 12})$$

The fitter must now adjust the shim to ensure pre-load on the bearings, as before.

The fitter should measure using the following method for the third and final gear:

- i) Dimension 15 = Bevel gear assembly mounting distance = 62.4
- ii) Dimension 16 = Measure assembly over bearings and spacer and record for later
- iii) Dimension 17 = Measure depth of housing bore
- iv) Dimension 18 = Intersection point of bores from End-face = 116

$$\text{SHIM 6} = \text{DIM 15} - (\text{DIM 18} - \text{DIM 17})$$

Assemble gear to pinion. If assembling a gear set, make sure that the matched teeth are properly engaged. The fitter now has to rotate the gears and check for smooth running. If necessary, adjust the shim to ensure smooth running. Only after positioning both gears at their mounting distances, and the fitter is satisfied with the "smooth" running, should the fitter measure the normal backlash to verify proper assembly. The fitter should measure at the tightest point of the mesh between the gears.

- v) Dimension 19 = Measure end-cap mounting face to bearing seat

$$\text{SHIM 7} = \text{DIM 17} - (\text{SHIM 6} + \text{DIM 16} + \text{DIM 19})$$

The fitter must now adjust the shim to ensure pre-load on the bearings as before.

Conclusion

The gearbox used in this guide is just an example; it incorporates right-angled bevel gears and acute-angled bevel gears. The way the pre-load is applied in this gearbox does not necessarily mean that this is the preferred method. This guide aims to provide the designer sufficient knowledge to design any type of gearbox involving bevel gears.

It must be remembered that due to the complex nature of the forces generated by transmitting power through bevel gears, along with the combination of thermal forces and tolerances of individual components, it is virtually impossible to fully predict the behavior of gears under full-load during its operating service.

However, if the designer and fitter use this guide as a basis to design and install bevel gears, it should in theory be possible to design and build a gearbox that runs under full-load with an ideal tooth contact pattern. ⚙️

References

1. Stadtfeld, Dr. Hermann J. Vice President/Bevel Gear Technology—R&D, Gleason Corporation.
2. Wasilewski, Robert F. Design Engineering Manager, Arrow Gear Company.
3. Wasilewski, Robert F. "How to Install Bevel Gears for Peak Performance," *Power Transmission Design*, March 1994.
4. Arvin, Joseph L. et al. "Spiral Bevel Gear Development: Eliminating Trial and Error with Computer Technology," January/February 2003 *Gear Technology*.
5. Arvin, Joseph L. and James J. Cervinka. "Gearing Up for Land, Sea and Air," *Gear Solutions*, February 2009.
6. Gleason Design Manual. *Assembling Bevel and Hypoid Gears*.

Stephen Marsh is an incorporated engineer (IEng) with the Engineering Council (UK) and the Institution of Mechanical Engineers, working primarily in the aerospace and nuclear industries. He began in 2000 a technical modern apprenticeship and an HNC in mechanical engineering with Rolls-Royce plc., and in 2005 graduated from the University of Central England with a BEng (Hons) degree in mechanical engineering, while working as a CAD engineer and draftsman on the HP compressor for the V2500 International Aero engines. Marsh later transferred to the Civil Aerospace Group—Transmissions, Structures and Drives in 2007, working on projects such as Trent 900, Trent 1000, ANTLE and EFE. He subsequently changed industries, moving to the nuclear sector as a design engineer for Nuclear Engineering Services Ltd., and then to UTC Aerospace Systems (formerly Goodrich Actuation Systems), where he currently works as a concept design engineer on projects such as designing the hydraulic actuators for the thrust reverser actuation system (TRAS) on the A320 NEO and designing the gearboxes and telescopic coupling for the variable-area fan nozzle (VAFN) actuation system.




Figure 18 Intersecting bores inside housing.




Figure 19 Location of shims.




Figure 20 Bevel gear assembly and intersecting bores inside housing.